



Suppliers of Air Conditioning & Refrigeration
Control Equipment
Unit 25/205-213 Port Hacking Rd Miranda 2228
Sydney Australia
Phone: +61 2 9522 0334 Fax: +61 2 9522 0337
www.mjbcontrols.com.au sales@mjbcontrols.com.au

ACCS-1 Quick setup guide:

Please note that the Air Conditioning System must be turned on to set any of the following options:

Setting the Time:

- 1) Press the **PROGRAM** button to place the wall controller in program mode.
- 2) Press the **UP / DOWN** buttons until the wall controller says **SET CLOCK**.
- 3) Press the **ENTER** button to enter clock set mode.
- 4) Press the **UP / DOWN** buttons the set the desired hour then press **ENTER**.
- 5) Press the **UP / DOWN** buttons to set the desired minutes then press **ENTER**.
- 6) Press the **UP / DOWN** buttons to set the seconds to zero then press **ENTER**.
- 7) The time has now been set. Press the **PROGRAM** button to save the new settings or press the **UP/DOWN** buttons to continue.

Setting the Date:

- 1) Press the **PROGRAM** button to place the wall controller in program mode.
- 2) Press the **UP / DOWN** buttons until the wall controller says **SET DATE**.
- 3) Press the **ENTER** button to enter date set mode.
- 4) Press the **UP / DOWN** buttons until the desired day then press **ENTER**.
- 5) Press the **UP / DOWN** buttons until the desired month then press **ENTER**.
- 6) Press the **UP / DOWN** buttons until the desired year then press **ENTER**.
- 7) The date has now been set. Press the **PROGRAM** button to save the new settings.

The correct weekday will be automatically set, e.g. **MONDAY** during the above procedure. If the day is incorrect please recheck, **DAY, MONTH AND YEAR**.

Manual Operation: (Cooling)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **COOL** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the ACCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Manual Operation: (Heating)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **HEAT** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the ACCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Auto Operation:

(Automatically changes between Cooling and Heating to maintain set temperature).

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **AUTO** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the ACCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Fan Only Operation: (Air circulation only)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **COOL HEAT AUTO** is NOT showing on the LCD.
- 3) Press the **FAN** button to set the desired fan speed (Hi, Mid, Low).
- 4) Press the **OFF** button to turn the system off.

Setting 7-Day programmable time clock:

- 1) Press the **ON** button.
- 2) Press the **PROGRAM** button to place the wall controller in program mode.
- 3) Press the **UP / DOWN** buttons until the wall controller says **SET TIMER**.
- 4) Press the **ENTER** button to enter timer mode.
- 5) **TICLR** will now be showing on the display, this means **TIMER1** is clear (no settings, if there was a previous setting then this will be displayed).
- 6) Press the **DOWN** button until **DAY1** shows on the display. From here you can choose from following days sequence's MONDAY to FRIDAY, MONDAY to SUNDAY, or individual days by pressing the **UP / DOWN** buttons. Once you have set your required days press the **ENTER** button to save.
- 7) **TI ON** time will now need to be set.
- 8) Press the **UP / DOWN** buttons to set the desired hour then press **ENTER**
- 9) Press the **UP / DOWN** buttons to set the desired minutes then press **ENTER**
- 10) **TI OFF** time will now need to be set.
- 11) Press the **UP / DOWN** buttons to set the desired hour then press **ENTER**
- 12) Press the **UP / DOWN** buttons to set the desired minutes then press **ENTER**
- 13) Should you wish to clear/cancel the timer function press the **UP / DOWN** buttons until **TI CLR** is displayed. This means you have cleared/cancelled the timer.

The time clock has a total of 4 timers, this allows for 4 different ON – OFF times over a 7-day period.

For example. If you wish to turn your Air Conditioner on at 8am and off at 10pm Monday to Friday, this can be achieved using the first timer T1

Should you wish to turn the Air Conditioner on at 9am and off at 11pm on Saturday only as well as the previous time periods this is achieved using the second timer T2 in conjunction with the first timer T1

Additional timers are set in the same manner as above. If you need more information please contact the place of purchase.

