



**Suppliers of Air Conditioning & Refrigeration
Control Equipment**

Unit 25/205-213 Port Hacking Rd Miranda 2228
Sydney Australia

Phone: +61 2 9522 0334 Fax: +61 2 9522 0337
www.mjbcontrols.com.au sales@mjbcontrols.com.au

WCCS-1 Quick setup guide:

Setting the Time and Date:

- 1) Press the **PROGRAM** button to place the wall controller in program mode.
- 2) Press the **UP / DOWN** buttons until the wall controller says **CLOCK**.
- 3) Press the **ENTER** button to enter clock set mode.
- 4) Press the **UP / DOWN** buttons the set the desired hour then press **ENTER**.
- 5) Press the **UP / DOWN** buttons to set the desired minutes then press **ENTER**.
- 6) Press the **UP / DOWN** buttons to set the desired seconds then press **ENTER**.
- 7) Press the **UP / DOWN** buttons until the desired day then press **ENTER**.
- 8) Press the **UP / DOWN** buttons until the desired month then press **ENTER**.
- 9) Press the **UP / DOWN** buttons until the desired year then press **ENTER**.
- 10) Press the **UP / DOWN** buttons until the desired weekday then press **ENTER**.
- 11) **SAVED** will now be shown on the LCD.
- 12) Press the **PROGRAM** button to exit setup.

Manual Operation: (Cooling)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **COOL** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the WCCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Manual Operation: (Heating)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **HEAT** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the WCCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Auto Operation:

(Automatically changes between Cooling and Heating to maintain set temperature).

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **AUTO** is shown on the LCD.
- 3) Press the **UP / DOWN** buttons to the desired temperature setting.
- 4) Press the **FAN** button to the desired fan speed (Hi, Mid, Low) or alternatively set the fan to **AUTO** mode if you would like the WCCS-1 to adjust the fan speed for you.
- 5) Press the **OFF** button to turn the system off.

Fan Only Operation: (Air circulation only)

- 1) Press the **ON** button.
- 2) Press the **MODE** button until **COOL HEAT AUTO** is NOT showing on the LCD.
- 3) Press the **FAN** button to set the desired fan speed (Hi, Mid, Low, Auto, or Continuous Fan).
- 4) Press the **OFF** button to turn the system off.

Setting 12 Hour Count Down Timer:

TBA:

Setting 7-Day Programmable Time Clock:

- 1) Press the **PROGRAM** button.
- 2) Press the **UP / DOWN** buttons till **TIMER** shows on the LCD.
- 3) Press the **ENTER** button. "1" will show on the LCD. (We are now setting timer one).
- 4) Press the **ENTER** button.
- 5) **START** will show on the LCD, followed by a blinking clock.
- 6) Press the **UP / DOWN** buttons till you get to the required hour. Then press **ENTER**.
- 7) Press the **UP / DOWN** buttons till you get the required minutes. Then press **ENTER**.
- 8) Press the **UP button** till you get the required day or group of days. E.G. Single day, Monday to Friday or Monday to Sunday. Press **ENTER**.
- 9) **STOP** will show on the LCD followed by a blinking clock.
- 10) Press the **UP / DOWN** buttons till you get to the required hour. Then press **ENTER**.
- 11) Press the **UP / DOWN** buttons till you get the required minutes. Then press **ENTER**.
- 12) **SAVED** will show on the LCD. You have now set timer "1" to turn the system on and off at your preset times.

The WCCS-1 has four timers, which you can use to set different on/off times E.G. Timer "1" for Monday to Friday, and the second timer "2" for Saturday and Sunday.

If you wish to turn your Air Conditioner on at 8am and off at 10pm Monday to Friday, this can be achieved using the first timer "1"

Should you wish to turn the Air Conditioner on at 9am and off at 11pm on Saturday only as well as the previous time periods this is achieved using the second timer "2" in conjunction with the first timer "1"

Additional timers are set in the same manner as above. If you need more information please contact the place of purchase.

